



INSTUCTIONS FOR INSTALLING TWEETER IN TO EXISTING TWEETER SPIDER

Will need the following tools:
flat head screwdriver
die grinder or dermal tool

1. Locate your tweeter spider from the speakers you removed from your lids. On the side of your speaker, you will see a small slot where you will be able to insert a screwdriver and pop off the tweeter spider from the top of the speaker.



2. Now Cut the area that connects the legs together between the mounting holes so it looks like this.



3. Once you have done that flip it upside down and remove the screws from the existing tweeter and pop it out the bottom.



4. Now you will need to use a Die Grinder or Dermal tool to up the tweeter hole for the new tweeter to fit.



5. Place the Tweeter in to the Hole and mount over your new 5 X 7 speakers.

