96-97 Wiring Conversion to updated

23 pin Harley connector colors

Left Side Control

Bike Wire Color	Radio Plug Wire Color	Radio Pin#
UP, Green/Blue	Green/Blue	23
IN, Brown/Black	Brown/Black	8
Down, Grey/Green	Grey/Green	22
Comm, Pink/White	Pink/White	3

Right Side Control

Bike Wire Color		Radio Plug Wire Color	Radio Pin#
UP,	Brown/White	Pink White	3
IN,	Violet/Black	Violet/Black	5
Down,	Grey/White	Grey/White	4
Comm,	, Orange/Black	Brown/White	6

<u>Left Speaker</u>		Radio Pin#		
Bike Wire Color				
+,	White/Orange	16		
-,	Light Green/White	17		
Right Speaker		Radio Pin#		
Bike Wire Color				
+,		4.0		
,	Grey/Red	18		

<u>Power</u>		Radio Pin #
Constant	Yellow	10
Switched	Red	12
Ground	Black	11